



Microbial MOS VS HYPO Comparison Table

A Compilation of Data Showing Mixed Oxidant Solution Superiority in Microbial Inactivation Compared to Hypochlorite (Bleach)

MIOX mixed oxidants have been proven in numerous laboratory studies to achieve more rapid and thorough inactivation of a wider range of microbial contaminants, including species highly resistant to chlorination, than conventional chlorine. The table below illustrates this point. Further, The MSR MIOX Purifier, the hand-held version of MIOX technology, passes the Environmental Protection Agency's (EPA's) Guide Standard and Protocol for Microbiological Purifiers, achieving more than the required inactivation level for viruses (4 log), bacteria (6 log), and protozoan oocysts (3 log) in both clean and dirty waters

Microorganism	MIOX Dose (mg/L)	Bleach Dose (mg/L)	Contact Time MIOX (min.)	Contact Time Bleach (min.)	Inactivation (log)	Differentiating Parameter	Reference
BACTERIA							
<i>Vibrio cholerae</i>	2	2	1.8	4.0	4 log	Time	Venczel et al, 2004
<i>Escherichia coli</i>	2	2	3.8	5.0	4 log	Time	Venczel et al, 2004
<i>Pseudomonas aeruginosa</i>	2	2	10	10	>4.8 MIOX 2.2 Bleach	Efficacy	Barton, 1996
<i>Legionella pneumophila</i>	2	2	10	10	>5.0 MIOX 4.7 Bleach	Efficacy	Barton, 1996
<i>Staphylococcus aureus</i>	2	2	60	60	1.6 MIOX 0.8 Bleach	Efficacy	Russell, 2001*
	4	4	60	60	3.7 MIOX 2.3 Bleach		
<i>Listeria monocytogenes</i>	2	2	60	60	2.0 MIOX 0.8 Bleach		
	4	4	60	60	3.7 MIOX 1.2 Bleach		
BACTERIAL SPORES							
<i>Bacillus sterothermophilus</i>	2	2	30	30	>5 MIOX 2.5 Bleach	Efficacy	Barton, 1996
<i>Clostridium perfringens spore</i>	2	2	13	18	2 log	Time	Venczel et al, 2004
<i>Bacillus globigii</i> spores <i>Bacillus anthracis</i> (Sterne) spores	2.5	2.5	15	15	3.6 MIOX 2.4 Bleach	Efficacy	Bajszar, 2008 and CDC, 2009†



Microorganism	MIOX Dose (mg/L)	Bleach Dose (mg/L)	Contact Time MIOX (min.)	Contact Time Bleach (min.)	Inactivation (log)	Differentiating Parameter	Reference
VIRUS							
<i>MS2 Coliphage</i>	2	2	70	168	4 log	Time	Venczel et al, 2004
Vaccinia (Smallpox Surrogate)	5	~70	20	10	4 log MIOX 3 log Bleach	Concentration Time Efficacy	Wright et al, 2001 Groupé, V. et al, 1955
Poliovirus Vaccine Strain 1	>4	NA	30	NA	>5.5 log MIOX	NA	Biovir, 2002
Rotavirus SA-11	>4	NA	30	NA	>5.5 log MIOX	NA	Biovir, 2002
PROTOZOAN OOCYSTS							
<i>Giardia lamblia</i>	>4	NA	30	NA	>4 log MIOX	NA	Biovir, 2002
<i>Cryptosporidium parvum</i> oocyst	5	5	240	1440	3, MIOX None, Bleach	Time and Efficacy	Venczel et al, 1997
<i>Cryptosporidium parvum</i> oocyst	25	25	240	240	>1, MIOX 0.25 Bleach	Efficacy, qRT-PCR and tissue culture infectivity	Bajszár & Dekonenko 2010

*These data were collected using the Impedance Detection Method (IDT) at pHs ranging from 6.5-9.0.

† Researchers at the Centers for Disease Control obtained similar results using a different strain of spore.



References:

- Bajszár, G. and Dekonenko, A. 2010 “Stress-induced Hsp70 Gene Expression and Inactivation of *Cryptosporidium parvum* oocysts by Chlorine-Based Oxidants” *Applied and Environmental Microbiology* 76, 6: 1732-1739.
- Bajszár, G. “Spore Inactivation Tests for Disinfectant Comparison and Biocidal Efficacy Assessment”, May 30, 2008.
- Barton, L.L., “Disinfection of Simulated Cooling Tower Water” Department of Biology, University of New Mexico, Albuquerque, NM, March, 4, 1996.
- BioVir Laboratories US EPA Guide Standard and Protocol for Testing Microbiological Purifiers, under the direction of Dr. Rick Danielson, “Product Microbial Disinfection Study fro Los Alamos Technical Associates Inc., MIOX™ Water Disinfection Pen” BioVir Laboratories, October 15, 2002.
- Dekonenko, A. and Bajszár, G. 2009. Disinfection of feline calicivirus (a human norovirus surrogate) on surfaces with chlorine-based mixed oxidant solution. *Internal Report* (manuscript in progress).
- Groupé, V., Engle, C.G., Gaffney, P.E. and Manker, R.A. 1955, “Virucidal Activity of Representative Antiinfective Agents Against Influenza A and Vaccinia Viruses,” *Applied and Environmental Microbiology*; 1955 3: 333-336
- Russell, S.M., “A Comparison of MIOX versus Bleach for Eliminating Pathogenic Bacteria Associated with Poultry Products”, Department of Poultry Science, University of Georgia, Athens, GA June 1, 2001.
- Rose, L., “Evaluation of the Efficacy of Mixed Oxidants on *Bacillus anthracis* (Sterne) Spores Associated with a Model Drinking Water Biofilm”. Center for Disease Control Reference #: NCPDCID-RC084947-00, Final Report May 12, 2009.
- Venczel, L.V., Likirdopulos, C.A, Robinson, C.E., and Sobsey, M.D., 2004, “Inactivation of Enteric Microbes in Water by Electro-chemical Oxidant from Brine (NaCl) and Free Chlorine,” *Water Science and Technology*; 50, 1; 141-146.
- Venczel, L.V., Arrowood, M., Hurd, M., and Sobsey, M.D., 1997 “Inactivation of *Cryptosporidium parvum* Oocysts and *Clostridium perfringens* Spores by a Mixed-Oxidant Disinfectant and by Free Chlorine,” *Applied and Environmental Microbiology*; 63, 4; 1598-1601.
- Wright, J.D., T.J. Dvorak, and B.G. Harper, 2001, “Interim Report: MIOX Disinfection Pen and the MesoSystems MesoStill™ Agents of Biological Origin (ABO) Disinfection Test”, Life Sciences Division, West Desert Test Center, U.S. Army proving Ground, Dugway, UT, Test Project No. 8-ES-225-MOX-001, WDTC Document No. WDTC-IR-01-047, May 2001.

